

## BioClean Product Information Sheet

# BioClean Glue Roll Gel

**BioClean Glue Roll Gel**, is a Ready-To-Use cleaning compound for cleaning glue-rolls and all other surfaces which are polluted with glue.

- Glue rolls
- Counter pressure rolls
- Glue tanks
- Glue pumps and stirring equipment
- Tools

### PRODUCT PROPERTIES:

Physical aspect	.....	orange/yellow liquid
Odour	.....	specific
Density	.....	1.05 ± 0,05 kg/l
Flashpoint	.....	none
Foam density	.....	low
Soluble in	.....	water
Solubility	.....	complete
Biodegradable	.....	yes
Phosphate-free	.....	yes
Normal working concentration	.....	Pure (ready to use)
Normal working temperature	.....	Room temperature.
pH undiluted	.....	2.3 ± 0,5

### SPECIAL PROPERTIES:

- The special raw materials in **BioClean Glue Roll Gel** are responsible for an effective cleaning.
- **BioClean Glue Roll Gel** dissolves very well glue remains, lime and their connections.
- Because of the thickness of **BioClean Glue Roll Gel** it is easy to apply on the surface of the Glue Roll and has a longer contact time to remove the glue.
- Does not contain complex formers which can be a problem for the effluent.
- **BioClean Glue Roll Gel** does not have any effect on effluent systems as far as we know.

### ADVANTAGES

- Can be used for all glue types in the paper industry.
- By using **BioClean Glue Roll Gel** the quality of the paper will be maintained.
- Long contact time due to the thickness of the BioClean Glue Roll Gel
- Safe for human and machine.

## **BioClean Product Information Sheet**

### **SAFE FOR:**

All water-repellent materials used in the glue systems in cardboard industries.  
Always check on a small spot if the **BioClean Glue Roll Gel** isn't harmful for the surface!

### **APPLICATION:**

#### **Cleaning from the Glue Roll.**

Apply the **BioClean Glue Roll Gel** pure on the Glue roll. During the cleaning let the glue rolls tumble. Cleaning time depends on the contamination but normally 60 minutes. You can accelerate the cleaning by brushing (copper brush) during cleaning. After cleaning rinse clean water. Rinse off with a high pressure cleaner will be helpful for a better cleaning.

### **SAFETY:**

During the use of **Bio Clean Glue Roll Gel** observe the standard workplace hygiene. For more information ask for our MSDS which will be sent to you on demand.

