

SELECT BY SURFACE

CERAMIC
Stainless steel

CHROME-PLATED
Phosphor bronze

FINE SCREEN / PLATES
Nylon

01



STAINLESS STEEL

APPLICATION

For manual cleaning of ceramic anilox rolls.

SPECIFICATION

Filament diameter: 0.08 mm or 0.10 mm

02



PHOSPHOR BRONZE

APPLICATION

For manual cleaning of chrome-plated anilox rolls.

SPECIFICATION

Filament diameter: 0.10 mm

03



NYLON

APPLICATION

For printing plates and ceramic or chrome-plated anilox rolls above 360 lines/cm.

SPECIFICATION

Non-metallic filament for fine-screen applications

GOOD CLEANING PRACTICE

1

Select the brush that matches the roll surface.

2

Apply a compatible cleaning agent and keep the surface wet.

3

Use light, controlled pressure; then rinse thoroughly.

!

IMPORTANT

Never use an anilox brush dry. Dry use, excessive pressure or the wrong brush may scratch or damage the roll surface.